## Important:

Make sure your page size in the print setup is set to "actual size" or "100%." Your options may look different based on your opperating system or program.

Do not set it to "Fit," or your seals will not be the correct size. Use the scale at the bottom to check after printing.

If printed correctly, these scales will be acurate.

7 inches

17 cm

2 15/16"

3 15/16"

7/32nd

Andrew Mingione
www.mingione.com